

# Installation :

- 1.Clean the wall: Use a damp cloth or detergent to remove dust, oil and other impurities from the wall to ensure that the wall is clean, dry and smooth to improve the adhesive effect.
- 2.Cutting the acoustics: According to the wall size and needs, use the cutting tool to cut the polyester grating wall panels into the appropriate size and shape.
- 3.Glue the acoustics: Attach the adhesive-coated polyester grating wall panels to the wall to make sure it is flat and free of air bubbles. Use a scraper to exhaust the air between the wall panel and the wall surface, so that the wall panel fits the wall surface tightly.
- 4.Reinforcement with studs: At the same time of pasting, it can be reinforced with studs to ensure the stability and firmness of the acoustics.

